



KEY-043-EU

Gold Cooling Mousse Eyeshadow

%	INGREDIENT	INCI NAME	SUPPLIER
Part 1			
80.49	Deionized Water	Water	
1.50	Volarest™ FL	Acrylates/Beheneth-25 Methacrylate Copolymer	Croda
Part 2			
0.11	Potassium Hydroxyde 85%	Potassium Hydroxyde	Acros Organics
Part 3			
2.90	WSJ20EYAMP-O	Water (And) Acrylates/Ethylhexyl Acrylate Copolymer (And) Iron Oxides (CI 77492) (And) Sodium Acrylate/Sodium Acryloyldimethyl Taurate Copolymer (And) Aminomethyl Propanol	Kobo Products
1.50	WSJ22ERAMP-O	Water (And) Acrylates/Ethylhexyl Acrylate Copolymer (And) Iron Oxides (CI 77491) (And) Sodium Acrylate/Sodium Acryloyldimethyl Taurate Copolymer (And) Aminomethyl Propanol	Kobo Products
0.60	WSJ22BNF-O	Water (And) Acrylates/Ethylhexyl Acrylate Copolymer (And) Iron Oxides (CI 77499) (And) Sodium Acrylate/Sodium Acryloyldimethyl Taurate Copolymer (And) Aminomethyl Propanol	Kobo Products
Part 4			
2.00	Crodamol™ ISIS	Isostearyl Isostearate	Croda
Part 5			
3.00	KTZ® BRONZE	Mica (And) Iron Oxides (CI 77491)	Kobo Products
1.50	KTZ® VIBRANT GOLD	Mica (And) Titanium Dioxide (And) Iron Oxides (CI 77491)	Kobo Products
1.00	SP-10	Nylon-12	Toray/Kobo Products
1.00	KTZ® UMBER	Mica (And) Iron Oxides (CI 77491)	Kobo Products
Part 6			
3.00	Glycerin	Glycerin	Interchimie
1.00	Hydrolite® 5	Pentylene Glycol	Symrise
0.20	SymDiol® 68	1,2-Hexanediol (and) Caprylyl Glycol	Symrise
0.20	AQUA KEEP 10SH-NFC	Sodium Acrylates Crosspolymer-2	Sumitomo Seika/Kobo Products
100.00			

Description:

AQUA KEEP 10SH-NF, Sodium Acrylates Crosspolymer-2, is used to thicken and to give a nice texture to this gel. Aqueous WSJ Dispersions help to incorporate and disperse pigments into the water gel while offering a strong water-resistant film. KTZ® BRONZE, KTZ® VIBRANT GOLD & KTZ® UMBER provide a bronze color and vibrant sparkle effect. SP-10 offers a creamy texture, gives glide upon application and an enhanced feel.

Manufacturing Procedure:

1. Disperse Volarest™ FL in water and add Part 2 to neutralize to pH 7.
2. Add Part 3 under stirring.
3. Add Part 4 under stirring.
4. Add Part 5 under stirring.
5. Premix Aqua Keep 10SH-NFC in glycerin and preservatives and add it to the batch under high stirring.



KOBO
www.koboproducts.com

October, 2014

FORMULATIONS

Product formulations are included as illustrative examples only. Kobo Products Inc. makes no representation or warranty concerning the efficacy or safety of any product manufactured using such formulations. All statements concerning the possible use of Kobo Products Inc. are for research purposes only. Responsibility for the performance or adequate testing of any product prior to sale or use of any such product lies with the manufacturer thereof.

USE OF PRODUCTS

Products sold by Kobo are designed, manufactured and sold for industrial use only. Prior to use of any such product for any application other than an industrial use, the user has the sole responsibility and obligation to determine the suitability of any such product for any such application.

PATENT STATUS

Nothing contained herein shall be construed to imply the nonexistence of any relevant patents or to constitute a permission, inducement or recommendation to practice any invention covered by any patent, without authority from the owner of the patent.

LIMITATION OF LIABILITY

Kobo Products Inc. shall in no event, whether the claim is based on warranty, contract, tort, strict liability, negligence or otherwise, be liable for incidental or consequential damages, or for any other damages in excess of the amount of the purchase price.

KOBO

The Powder & Dispersion Specialist



KOBO PRODUCTS, INC
3474 South Clinton Avenue
South Plainfield, NJ 07080
USA

Tel: +1 - 908 757 0033
Fax: +1 - 908 757 0905



KOBO BRASIL, LTDA
Rua Francisco Nakazato n. 2357
Itupeva SP 13.295-000
BRASIL

Tel: +55 (11) 5062 6034



KOBO PRODUCTS, LTD
67D(IV), Innovation Drive
Milton Park, Abingdon, OX14 4RQ
UNITED KINGDOM

Tel: +44 7913 636 673



KOBO PRODUCTS, SAS
135 Rue Buissonnière
Quartier Bouysset
31670 Labège
FRANCE

Tel: +33 - (0) 5 62 88 77 40
Fax: +33 - (0) 5 62 88 77 49



KOBO DISPATEK, INC
1-4-8 Nihombashi-bakurocho
Chuoko, Tokyo, 103-0002
JAPAN

Tel: +81 - 3 3663 8049
Fax: +81 - 3 3661 8679

www.koboproducts.com