



KFL-244A

# Body-Heat-Activated Facial Mask with KOBOGUARD® 5400 NH

%	INGREDIENT	INCI NAME	SUPPLIER
<b>Part 1</b>			
45.18	Deionized Water	Water	
4.00	Chemonix® LI-7	PEG-7 Glyceryl Cocoate	Lubrizol
3.00	PROPYLENE GLYCOL	Propylene Glycol	Ruger Chemical
3.00	Glycerin U.S.P. Natural 96%	Glycerin	Ruger Chemical
1.00	Luviquat® PQ 11 PN	Polyquaternium-11	BASF
0.90	Phenoxetol®	Phenoxyethanol	Ashland
0.02	Citric Acid USP Anhydrous Fine Granular	Citric Acid	Universal Preserv-A-Chem, Inc.
<b>Part 2</b>			
1.00	ETHYL ALCOHOL E1028	Ethyl Alcohol	PCI Scientific Supply Company
<b>Part 3</b>			
18.00	Emulgin® B 2	Ceteareth 21	Cognis
12.90	Squalane NF	Squalane	Barnet
2.00	KOBOGUARD® 5400 NH	Hydrogenated Polycyclopentadiene (And) C13-15 Alkane	Kobo Products
<b>Part 4</b>			
8.00	K-RAY® PERPETUAL SUMMIT BLUE	Titanium Dioxide (And) Mica (And) Silica	Kobo Products
1.00	KTZ® SM EXTRAFINE DENIM	Synthetic Fluorphlogopite (And) Titanium Dioxide (And) Ferric Ferrocyanide	Kobo Products
100.00			

## Description:

This facial mask is body-heat-activated upon application which melts the product into a shiny, oily layer. Skin is intensely hydrated, looking refreshed and healthy once the mask treatment is completed and face is cleansed from impurities. KOBOGUARD® 5400 NH is added to intensify the experience of transformation for optimized timing. K-RAY® PERPETUAL SUMMIT BLUE is an effect pigment that gives a unique stand-out blue reflection color. KTZ® SM EXTRAFINE DENIM provides background color and extra vibrancy.

## Manufacturing Procedure:

1. Combine Part 1. Prop mix. Heat to 80° C.
2. Combine Part 3. Prop mix. Heat to 80° C.
3. Add Part 2 to Part 1 then add Part 3 slowly to batch.
4. Add Part 4 to batch. Allow to mix for 10min.
5. Pour into glass jars at 80° C and allow to cool to RT.



**KOBO**  
www.koboproducts.com

March, 2020

## FORMULATIONS

Product formulations are included as illustrative examples only. Kobo Products Inc. makes no representation or warranty concerning the efficacy or safety of any product manufactured using such formulations. All statements concerning the possible use of Kobo Products Inc. are for research purposes only. Responsibility for the performance or adequate testing of any product prior to sale or use of any such product lies with the manufacturer thereof.

## USE OF PRODUCTS

Products sold by Kobo are designed, manufactured and sold for industrial use only. Prior to use of any such product for any application other than an industrial use, the user has the sole responsibility and obligation to determine the suitability of any such product for any such application.

## PATENT STATUS

Nothing contained herein shall be construed to imply the nonexistence of any relevant patents or to constitute a permission, inducement or recommendation to practice any invention covered by any patent, without authority from the owner of the patent.

## LIMITATION OF LIABILITY

Kobo Products Inc. shall in no event, whether the claim is based on warranty, contract, tort, strict liability, negligence or otherwise, be liable for incidental or consequential damages, or for any other damages in excess of the amount of the purchase price.

# KOBO

## *The Powder & Dispersion Specialist*



**KOBO PRODUCTS, INC**  
3474 South Clinton Avenue  
South Plainfield, NJ 07080  
USA

Tel: +1 - 908 757 0033  
Fax: +1 - 908 757 0905



**KOBO BRASIL, LTDA**  
Rua Francisco Nakazato n. 2357  
Itupeva SP 13.295-000  
BRASIL

Tel: +55 (11) 5062 6034



**KOBO PRODUCTS, LTD**  
67D(IV), Innovation Drive  
Milton Park, Abingdon, OX14 4RQ  
UNITED KINGDOM

Tel: +44 7913 636 673



**KOBO PRODUCTS, SAS**  
135 Rue Buissonnière  
Quartier Bouysset  
31670 Labège  
FRANCE

Tel: +33 - (0) 5 62 88 77 40  
Fax: +33 - (0) 5 62 88 77 49



**KOBO DISPATEK, INC**  
1-4-8 Nihombashi-bakurocho  
Chuoko, Tokyo, 103-0002  
JAPAN

Tel: +81 - 3 3663 8049  
Fax: +81 - 3 3661 8679

[www.koboproducts.com](http://www.koboproducts.com)

[www.koboproducts.com](http://www.koboproducts.com)