



KLG-095

One Color, One Look Lip Gloss

%	INGREDIENT	INCI NAME	SUPPLIER
Part 1			
24.00	Panalene® H-300E	Hydrogenated Polyisobutene	Vantage
20.00	Indopol® H-100	Polybutene	Vantage
15.00	KOBOGUARD® 5400 CCT	Hydrogenated Polycyclopentadiene (And) Caprylic/Capric Triglyceride	Kobo Products
14.00	Neosolue™-DiSM	Diisostearyl Malate	Nippon/Kobo Products
8.00	SALACOS® 5418V	Pentaerythrityl Tetraistearate	Ikeda
3.00	SunBoost ATB	Argania Spinosa Kernel Oil (And) Tocopheryl Acetate (And) Bisabolol	Kobo Products
2.00	PM WAX 82	Polyethylene (And) Microcrystalline Wax	Toray/Kobo Products
2.00	Plandool™-MAS	Phytosteryl Macadamiate	Nippon/Kobo Products
2.00	Plandool™-LG1	Phytosteryl/Behenyl/Octyldodecyl Lauroyl Glutamate	Nippon/Kobo Products
2.00	Bentone Gel® PTIS	Pentaerythrityl Tetraistearate (and) Distearidimonium Hectorite (and) Propylene Carbonate	Elementis
1.00	Lexgard® Natural	Glyceryl Caprylate (And) Glyceryl Undecylenate	Inolex
Part 2			
3.00	KTZ® FINE WHITE	Mica (And) Titanium Dioxide	Kobo Products
2.00	DOP70USG	Titanium Dioxide (And) Diisostearyl Malate (And) Octyldodecanol (And) Polyglyceryl-2 Triisostearate (And) Stearoyl Glutamic Acid	Kobo Products
2.00	DOP65RSG	Iron Oxides (CI 77491) (And) Diisostearyl Malate (And) Octyldodecanol (And) Polyglyceryl-2 Triisostearate (And) Stearoyl Glutamic Acid	Kobo Products
100.00			

Description:

This high shine cushion lip gloss has a neutral shade that is suitable for daily wear. The combination of Kobo's DOP dispersions and KTZ® FINE WHITE provide the peachy nude shade. Neosolue™-DiSM contributes to a smoother texture and emolliency of the formula on the lips. SunBoost ATB is a proprietary ratio of antioxidant, anti-irritant and anti-inflammatory agents used in this formula for a moisturizing effect. KOBOGUARD® 5400 CCT adds shine while also forming a flexible film, which helps improve wear. PM WAX 82 adds cushion and helps with stability. The combination of Plandool™-MAS and Plandool™-LG1 provides skin barrier moisture protection and improves wear.

Manufacturing Procedure:

1. Combine Part 1 and heat to 85° C while propeller mixing.
2. When waxes are melted, begin cooling to room temperature and add Part 2.
3. Add Part 3 and mix until batch is uniform.



KOBO
www.koboproducts.com

November, 2019

FORMULATIONS

Product formulations are included as illustrative examples only. Kobo Products Inc. makes no representation or warranty concerning the efficacy or safety of any product manufactured using such formulations. All statements concerning the possible use of Kobo Products Inc. are for research purposes only. Responsibility for the performance or adequate testing of any product prior to sale or use of any such product lies with the manufacturer thereof.

USE OF PRODUCTS

Products sold by Kobo are designed, manufactured and sold for industrial use only. Prior to use of any such product for any application other than an industrial use, the user has the sole responsibility and obligation to determine the suitability of any such product for any such application.

PATENT STATUS

Nothing contained herein shall be construed to imply the nonexistence of any relevant patents or to constitute a permission, inducement or recommendation to practice any invention covered by any patent, without authority from the owner of the patent.

LIMITATION OF LIABILITY

Kobo Products Inc. shall in no event, whether the claim is based on warranty, contract, tort, strict liability, negligence or otherwise, be liable for incidental or consequential damages, or for any other damages in excess of the amount of the purchase price.

KOBO

The Powder & Dispersion Specialist



KOBO PRODUCTS, INC
3474 South Clinton Avenue
South Plainfield, NJ 07080
USA

Tel: +1 - 908 757 0033
Fax: +1 - 908 757 0905



KOBO BRASIL, LTDA
Rua Francisco Nakazato n. 2357
Itupeva SP 13.295-000
BRASIL

Tel: +55 (11) 5062 6034



KOBO PRODUCTS, LTD
67D(IV), Innovation Drive
Milton Park, Abingdon, OX14 4RQ
UNITED KINGDOM

Tel: +44 7913 636 673



KOBO PRODUCTS, SAS
135 Rue Buissonnière
Quartier Bouysset
31670 Labège
FRANCE

Tel: +33 - (0) 5 62 88 77 40
Fax: +33 - (0) 5 62 88 77 49



KOBO DISPATEK, INC
1-4-8 Nihombashi-bakurocho
Chuoko, Tokyo, 103-0002
JAPAN

Tel: +81 - 3 3663 8049
Fax: +81 - 3 3661 8679

www.koboproducts.com

www.koboproducts.com