



KLG-113A-EU

A good night's sleep for lips

%	INGREDIENT	INCI NAME	SUPPLIER
Part 1			
22.70	Panalane H300	Hydrogenated Polybutene	Vantage
14.00	Akogel	Hydrogenated Vegetable Oil	AAK
14.00	Neosolue™-DiSM	Diisostearyl Malate	Nippon Fine Chemical/Kobo Products
12.00	Plandool™-H	Phytosteryl/Isostearyl/Cetyl/Stearyl/Behenyl Dimer Dilinoleate	Nippon Fine Chemical/Kobo Products
8.34	Dub PTO	Pentaerythrityl tetraethylhexanoate	Stearinerie Dubois
8.00	DISM10M5	Diisostearyl Malate (And) Silica	Kobo Products
4.00	CELLULOBEADS D-5-ASG3	Cellulose (And) Stearoyl Glutamic Acid	Kobo Products
4.00	Beeswax Yellow	Beeswax	Koster Keunen
3.00	Plurol Diisostearique	Polyglyceryl-3 Diisostearate	Gattefosse
2.00	Akofine P	Hydrogenated Vegetable Oil	AAK
1.00	Lexguard Natural MB	Glyceryl Caprylate (and) Glyceryl Undecylenate	Inolex
1.00	MSS-500/3H	Silica	Kobo Products
Part 2			
3.50	Glycerin	Glycerin	Interchemie
2.00	Water	Aqua	x
0.25	Cn-HAHWS	Water (And) Pentylene Glycol (And) Palmitoyl Hydroxypropyltrimonium Amylopectin/Glycerin Crosspolymer (And) 1,2-Hexanediol (And) Caprylyl Glycol (And) Sodium Hyaluronate (And) Hydrogenated Lecithin	Kobo Products
Part 3			
0.20	SW65U	Synthetic Wax (And) Titanium Dioxide (And) Isopropyl Titanium Triisostearate	Kobo Products
0.01	SW40R7C	Synthetic Wax (And) Red 7 Lake (And) Isopropyl Titanium Triisostearate	Kobo Products
100.00			

Description:

This lip mask is the way to go if you wish to have ever so nourished and soft lips overnight. This formula is substantive to the lips without ever feeling sticky. Apply it on the lips before you go to bed as a part of your night time skincare routine. This formula includes Cn-HAHWS, encapsulated Sodium Hyaluronate for enhanced penetration, which could provide increased hydration as well as enhanced collagen synthesis in the lips. It also contains Neosolue™-DiSM which is a unique ester low viscosity ester with high water holding capacity and Plandool™-H, a lanolin replacement ester that provides adhesion and locks the moisture in the skin. DISM10M5 is a silica gellant providing thickening. MSS-500/3H, a silica microsphere, prevents sweating on surface of the lip mask. CELLULOBEADS D5-ASG3 gives the product a cushiony feel upon application. SW65U & SW40R7C, our Synthetic Wax dispersions have been used to give a hint of colour.

Manufacturing Procedure:

1. Weigh powders of Part 1 and add Neosolue DiSM to wet them. Add rest of Part 1 ingredients and mix. Heat upto 80 degree C and mix.
2. Prepare Part 2 and add to Part 1, keeping batch at 80 degrees C
3. Add Part 3 and mix. Pour into glass jar at 75 degrees C



KOBO
www.koboproducts.com

August, 2023

FORMULATIONS

Product formulations are included as illustrative examples only. Kobo Products Inc. makes no representation or warranty concerning the efficacy or safety of any product manufactured using such formulations. All statements concerning the possible use of Kobo Products Inc. are for research purposes only. Responsibility for the performance or adequate testing of any product prior to sale or use of any such product lies with the manufacturer thereof.

USE OF PRODUCTS

Products sold by Kobo are designed, manufactured and sold for industrial use only. Prior to use of any such product for any application other than an industrial use, the user has the sole responsibility and obligation to determine the suitability of any such product for any such application.

PATENT STATUS

Nothing contained herein shall be construed to imply the nonexistence of any relevant patents or to constitute a permission, inducement or recommendation to practice any invention covered by any patent, without authority from the owner of the patent.

LIMITATION OF LIABILITY

Kobo Products Inc. shall in no event, whether the claim is based on warranty, contract, tort, strict liability, negligence or otherwise, be liable for incidental or consequential damages, or for any other damages in excess of the amount of the purchase price.

KOBO

*The Powder & Dispersion
Specialist*



KOBO PRODUCTS, INC
3474 South Clinton Avenue
South Plainfield, NJ 07080
USA

Tel: +1 - 908 757 0033
Fax: +1 - 908 757 0905



KOBO BRASIL, LTDA
Rua Francisco Nakazato n. 2357
Itupeva SP 13.295-000
BRASIL

Tel: +55 (11) 5062 6034



KOBO PRODUCTS, LTD
67D(IV), Innovation Drive
Milton Park, Abingdon, OX14 4RQ
UNITED KINGDOM

Tel: +44 7913 636 673



KOBO PRODUCTS, SAS
135 Rue Buissonnière
Quartier Bouysset
31670 Labège
FRANCE

Tel: +33 - (0) 5 62 88 77 40
Fax: +33 - (0) 5 62 88 77 49



KOBO DISPATEK, INC
1-4-8 Nihombashi-bakurocho
Chuoko, Tokyo, 103-0002
JAPAN

Tel: +81 - 3 3663 8049
Fax: +81 - 3 3661 8679

www.koboproducts.com