



KLP-110A-BR Velvet Liquid Lipstick

%	INGREDIENT	INCI NAME	SUPPLIER
Part 1			
16.00	CXG-1104	Dimethicone (And) Dimethicone/Vinyl Dimethicone Crosspolymer	Avantor/Kobo Products
10.00	COSMOL™ 222	Diisostearyl Malate	Ikeda/Kobo Products
8.00	KOBOGUARD® HRPC	Hydrogenated Polycyclopentadiene (And) Polyethylene (And) Copernicia Cerifera (Carnauba) Wax (And) Tocopherol	Kobo Products
8.00	INBP45R7C	Red 7 Lake (And) Isononyl Isononanoate (And) Isopropyl Myristate (And) Stearalkonium Hectorite (And) Isopropyl Titanium Triisostearate (And) Propylene Carbonate (And) Polyhydroxystearic Acid	Kobo Products
8.00	Xiameter PMX-0245	Cyclopentasiloxane	Dow Corning
5.00	COSMOL™ 168ARV	Dipentaerythryl Hexahydroxystearate/Hexastearate/Hexarosinate	Ikeda/Kobo Products
5.00	Xiameter PMX-200 Silicone Fluid 20CS	Dimethicone	Dow Corning
3.00	Tecwax Ozoquerita	Ozokerite Wax	Cosmotec
3.00	PM WAX 82	Polyethylene (And) Microcrystalline Wax	Toray/Kobo Products
3.00	INBP50R33A	Red 33 Lake (And) Isononyl Isononanoate (And) Isopropyl Myristate (And) Stearalkonium Hectorite (And) Polyhydroxystearic Acid (And) Isopropyl Titanium Triisostearate (And) Propylene Carbonate	Kobo Products
3.00	COSMOL™ 43V	Polyglyceryl-2 Triisostearate	Ikeda/Kobo Products
2.00	DC 556	Phenyl Trimethicone	Dow Corning
2.00	Tecwax Abelha	Beeswax	Cosmotec
Part 2			
8.00	MSS-500W	Silica	Kobo Products
4.00	SP-10	Nylon-12	Toray/Kobo Products
Part 3			
6.00	Xiameter PMX-0245	Cyclopentasiloxane	Dow Corning
6.00	Permethyl® 99A	Isododecene	Cosmotec
100.00			

Description:

This Velvet Liquid Lipstick features Avantor Silicones. COSMOL™ 222 and COSMOL™ 43V are esters that help in the dispersion of the pigments and enhanced feel. PM WAX 82 helps with the structure. COSMOL™ 168ARV improves moisture and provides enhanced feel. CXG-1104 is an elastomer gel that gives a silky, powdery feel and velvet effect. INBP are pigmentary dispersions in Isononyl Isononanoate that provide a fully developed color. KOBOGUARD® HRPC gives structure to the formula while forming a long-lasting film. Microspheres SP-10 and MSS-500W give a beautiful, velvety look to the lips.

Manufacturing Procedure:

1. Mix Part 1 and heat to 85°C.
2. Cool to 70°C and add Parts 2 and 3.
3. Pour into components.



FORMULATIONS

Product formulations are included as illustrative examples only. Kobo Products Inc. makes no representation or warranty concerning the efficacy or safety of any product manufactured using such formulations. All statements concerning the possible use of Kobo Products Inc. are for research purposes only. Responsibility for the performance or adequate testing of any product prior to sale or use of any such product lies with the manufacturer thereof.

USE OF PRODUCTS

Products sold by Kobo are designed, manufactured and sold for industrial use only. Prior to use of any such product for any application other than an industrial use, the user has the sole responsibility and obligation to determine the suitability of any such product for any such application.

PATENT STATUS

Nothing contained herein shall be construed to imply the nonexistence of any relevant patents or to constitute a permission, inducement or recommendation to practice any invention covered by any patent, without authority from the owner of the patent.

LIMITATION OF LIABILITY

Kobo Products Inc. shall in no event, whether the claim is based on warranty, contract, tort, strict liability, negligence or otherwise, be liable for incidental or consequential damages, or for any other damages in excess of the amount of the purchase price.

KOBO

The Powder & Dispersion Specialist



KOBO PRODUCTS, INC
3474 South Clinton Avenue
South Plainfield, NJ 07080
USA

Tel: +1 - 908 757 0033
Fax: +1 - 908 757 0905



KOBO BRASIL, LTDA
Rua Francisco Nakazato n. 2357
Itupeva SP 13.295-000
BRASIL

Tel: +55 (11) 5062 6034



KOBO PRODUCTS, LTD
67D(IV), Innovation Drive
Milton Park, Abingdon, OX14 4RQ
UNITED KINGDOM

Tel: +44 7913 636 673



KOBO PRODUCTS, SAS
135 Rue Buissonnière
Quartier Bouysset
31670 Labège
FRANCE

Tel: +33 - (0) 5 62 88 77 40
Fax: +33 - (0) 5 62 88 77 49



KOBO DISPATEK, INC
1-4-8 Nihombashi-bakurocho
Chuoko, Tokyo, 103-0002
JAPAN

Tel: +81 - 3 3663 8049
Fax: +81 - 3 3661 8679

www.koboproducts.com