



KPP-134A

Talc- Free Bronzer

%	INGREDIENT	INCI NAME	SUPPLIER
Part 1			
22.50	MICA S-ASG3	Mica (And) Stearoyl Glutamic Acid	Kobo Products
12.95	CARESS® BN06	Boron Nitride	Bent Tree/Kobo Products
10.00	MSS-500/N	Silica	Kobo Products
5.00	ZINC MYRISTATE (MB)	Zinc Myristate	Kobo Products
2.00	BTD-ASGP3	Titanium Dioxide (And) Stearoyl Glutamic Acid (And) Polyhydroxystearic Acid	Kobo Products
1.00	Lexgard® Natural MB	Glyceryl Caprylate (and) Glyceryl Undecylenate	Inolex
0.80	BWYO-ASGP3	Iron Oxides (CI 77492) (And) Stearoyl Glutamic Acid (And) Polyhydroxystearic Acid	Kobo Products
0.50	BWRO-ASGP3	Iron Oxides (CI 77491) (And) Stearoyl Glutamic Acid (And) Polyhydroxystearic Acid	Kobo Products
0.25	BWBO-ASGP3	Iron Oxides (CI 77499) (And) Stearoyl Glutamic Acid (And) Polyhydroxystearic Acid	Kobo Products
Part 2			
15.00	Pelemol® CCT	Caprylic/Capric Triglyceride	Phoenix Chemical
Part 3			
20.00	KTZ® SM CRYSTAL GOLD	Synthetic Fluorphlogopite (And) Iron Oxides (CI 77491) (And) Silica	Kobo Products
9.00	KTZ® ARUBAN CORAL	Mica (And) Titanium Dioxide (And) Iron Oxides (CI 77491)	Kobo Products
1.00	KTZ® EBONY	Iron Oxides (CI 77499) (And) Mica	Kobo Products
100.00			

Description:

A soft bronzer that blends seamlessly for a lightweight luminous glow. This talc-free unique formula allows for an effortless application of color and radiance. It leaves skin with a healthy appearance and glow when the bronzer is brushed on and blends in like second skin. The ASGP-treated pigments and MICA S-ASG3 (used as a talc substitution) provide the creamy feel and aid with pressability. ZINC MYRISTATE (MB) is used as an additional dry binder. CARESS® BN06, Boron Nitride, is used for superior softness and tactility, superb spreadability, excellent adherence, long lasting effect and good coverage. MSS-500/N provides a soft focus effect while helping to fill in lines and wrinkles. KTZ® SM CRYSTAL GOLD adds an intense, gold sparkling effect. KTZ® ARUBAN CORAL gives light radiance to the skin. KTZ® EBONY, a unique black pearl, provides a smoky color with a satin look.

Manufacturing Procedure:

1. Combine Part 1. Micropulverize until fully dispersed.
2. Add Part 2 to Part 1. Micropulverize until uniform.
3. Add Part 3 to batch. Micropulverize until uniform.
4. Press at 1000psi.



KOBO
www.koboproducts.com

December, 2021

FORMULATIONS

Product formulations are included as illustrative examples only. Kobo Products Inc. makes no representation or warranty concerning the efficacy or safety of any product manufactured using such formulations. All statements concerning the possible use of Kobo Products Inc. are for research purposes only. Responsibility for the performance or adequate testing of any product prior to sale or use of any such product lies with the manufacturer thereof.

USE OF PRODUCTS

Products sold by Kobo are designed, manufactured and sold for industrial use only. Prior to use of any such product for any application other than an industrial use, the user has the sole responsibility and obligation to determine the suitability of any such product for any such application.

PATENT STATUS

Nothing contained herein shall be construed to imply the nonexistence of any relevant patents or to constitute a permission, inducement or recommendation to practice any invention covered by any patent, without authority from the owner of the patent.

LIMITATION OF LIABILITY

Kobo Products Inc. shall in no event, whether the claim is based on warranty, contract, tort, strict liability, negligence or otherwise, be liable for incidental or consequential damages, or for any other damages in excess of the amount of the purchase price.

KOBO

The Powder & Dispersion Specialist



KOBO PRODUCTS, INC
3474 South Clinton Avenue
South Plainfield, NJ 07080
USA

Tel: +1 - 908 757 0033
Fax: +1 - 908 757 0905



KOBO BRASIL, LTDA
Rua Francisco Nakazato n. 2357
Itupeva SP 13.295-000
BRASIL

Tel: +55 (11) 5062 6034



KOBO PRODUCTS, LTD
67D(IV), Innovation Drive
Milton Park, Abingdon, OX14 4RQ
UNITED KINGDOM

Tel: +44 7913 636 673



KOBO PRODUCTS, SAS
135 Rue Buissonnière
Quartier Bouysset
31670 Labège
FRANCE

Tel: +33 - (0) 5 62 88 77 40
Fax: +33 - (0) 5 62 88 77 49



KOBO DISPATEK, INC
1-4-8 Nihombashi-bakurocho
Chuoko, Tokyo, 103-0002
JAPAN

Tel: +81 - 3 3663 8049
Fax: +81 - 3 3661 8679

www.koboproducts.com

www.koboproducts.com