



KPP-136

Foundation Tablet

%	INGREDIENT	INCI NAME	SUPPLIER
Part 1			
45.80	GMS-ASGP4	Mica (And) Stearoyl Glutamic Acid (And) Polyhydroxystearic Acid	Kobo Products
10.50	SIH-5 TiO2 R250	Titanium Dioxide (And) Silica (And) Aluminum Hydroxide	Daito/Kobo Products
6.00	ImerCare® 08K(S)	Kaolin	Imerys
5.00	Avicel® PC 591	Microcrystalline Cellulose (and) Cellulose Gum	FMC Biopolymer/ Earth Supplied Science
5.00	MSS-500W	Silica	Kobo Products
3.50	MST MAKIGREEN CORN S	Zea Mays (Corn) Starch (And) Magnesium Stearate	Daito/Kobo Products
3.30	SIH-2 YELLOW No.602P	Iron Oxides (CI 77492) (And) Silica	Daito/Kobo Products
2.00	ZINC MYRISTATE (MB)	Zinc Myristate	Kobo Products
2.00	CELLULOBEADS D-10	Cellulose	Daito/Kobo Products
1.00	Lexgard® Natural MB	Glyceryl Caprylate (and) Glyceryl Undecylenate	Inolex
1.00	INULIN-SC	Inulin	Nippon/Kobo Products
1.00	Amihope OL	N-Capryloyl-lysine	Ajinomoto Health & Nutrition North America, Inc.
0.90	SIH-2 RED No.211P	Iron Oxides (CI 77491) (And) Silica	Daito/Kobo Products
0.50	SIH-2 BLACK No.710P	Iron Oxides (CI 77499) (And) Silica	Daito/Kobo Products
Part 2			
6.00	Protachem ISP	Isostearyl Palmitate	Protameen
6.00	Eversoft UCS-40S	Disodium Cocoyl Glutamate	Sino Lion
0.50	JEECOL LA-7	Laureth-7	Jeen International
100.00			

Description:

One tablet creates a lightweight, sheer tinted foundation to provide a healthy and even complexion. Just add water to the tablet. More water creates a sheer formula and less water creates more coverage. This is a talc-free formulation. This formula features SIH pigments treated with hydrophilic silica which are used to create the shade and coverage. Pigments with this treatment disperse well in water. MSS-500W adds slip and even coverage as well as soft focus effect on the skin. CELLULOBEADS D-10 contributes softness. ZINC MYRISTATE (MB) is used as the dry binder. INULIN-SC is a sugar cane derived polysaccharide that provides a moisturizing effect. GMS-ASGP4 gives a nice feel while improving pressability. MST MAKIGREEN CORN S is a natural filler that provides a silky texture.

Manufacturing Procedure:

1. Blend Part 1 until fully uniform. Add Part 2 and blend until uniform.
2. Lubricate the pill press with Protachem ISP. Press in tablet maker.

How to Use:

Add desired amount of water to tablet. Mix until dispersed and apply to face with dampened sponge.

Note:

Less Water = More Coverage
More Water = Less coverage/ More Sheer Tint



KOBO
www.koboproducts.com

August, 2021

FORMULATIONS

Product formulations are included as illustrative examples only. Kobo Products Inc. makes no representation or warranty concerning the efficacy or safety of any product manufactured using such formulations. All statements concerning the possible use of Kobo Products Inc. are for research purposes only. Responsibility for the performance or adequate testing of any product prior to sale or use of any such product lies with the manufacturer thereof.

USE OF PRODUCTS

Products sold by Kobo are designed, manufactured and sold for industrial use only. Prior to use of any such product for any application other than an industrial use, the user has the sole responsibility and obligation to determine the suitability of any such product for any such application.

PATENT STATUS

Nothing contained herein shall be construed to imply the nonexistence of any relevant patents or to constitute a permission, inducement or recommendation to practice any invention covered by any patent, without authority from the owner of the patent.

LIMITATION OF LIABILITY

Kobo Products Inc. shall in no event, whether the claim is based on warranty, contract, tort, strict liability, negligence or otherwise, be liable for incidental or consequential damages, or for any other damages in excess of the amount of the purchase price.

KOBO

The Powder & Dispersion Specialist



KOBO PRODUCTS, INC
3474 South Clinton Avenue
South Plainfield, NJ 07080
USA

Tel: +1 - 908 757 0033
Fax: +1 - 908 757 0905



KOBO BRASIL, LTDA
Rua Francisco Nakazato n. 2357
Itupeva SP 13.295-000
BRASIL

Tel: +55 (11) 5062 6034



KOBO PRODUCTS, LTD
67D(IV), Innovation Drive
Milton Park, Abingdon, OX14 4RQ
UNITED KINGDOM

Tel: +44 7913 636 673



KOBO PRODUCTS, SAS
135 Rue Buissonnière
Quartier Bouysset
31670 Labège
FRANCE

Tel: +33 - (0) 5 62 88 77 40
Fax: +33 - (0) 5 62 88 77 49



KOBO DISPATEK, INC
1-4-8 Nihombashi-bakurocho
Chuoko, Tokyo, 103-0002
JAPAN

Tel: +81 - 3 3663 8049
Fax: +81 - 3 3661 8679

www.koboproducts.com